


WESTMINSTER BASIC™

www.decoflame.com

Westminster Basic is a built-in bioethanol fireplace featuring the Denver Basic automatic burner.

Featuring the e-Ribbon Fire™ burning system, Westminster Basic® is suitable for various fireplace applications, where safety and ease of use are in focus.



WESTMINSTER BASIC™

Westminster Basic 2D DWG

Westminster Basic 3D STEP

Westminster Basic Stone surround 2D DWG


Westminster Basic Stone surround 3D STEP

FEATURES

- e-Ribbon™ technology
- Fuel level indicator
- Flame level indicator
- 3 flame levels
- Safety sensors
- No chimney required
- 2mm Steel casing and baseplate
- Black
- Safety chamber
- Child lock

OPTIONAL

- Upgrade to Bluetooth / App and six flame levels
- 80mm high glass screen to front
- Stone surrounding



TECHNICAL INFORMATION

Flame tray size: 500mm

Capacity: 4L

Fuel consumption: 0,2 - 0,55 l/h

Burning time: 7h - 20h




Heat output: 1,2 - 3,2 kW

Net weight: 60 kg


Minimum room size: 64m³

Power supply: 220V - 240V - 50 Hz

Finish: Powder-coated Steel and brushed/polished stainless steel



Control Panel



Service USB

Flame level Indicator

Fuel Level Indicator

Start / Stop

Flame level Up

On / Off

Flame level Down



Step 1: Make sure that the dimensions of the wall cut-out correspond to the those indicated in the technical drawing received with your fireplace.

Step 2: (If purchased, place the stones or round against the wall) Recess the fireplace into the wall cut-out according to the indications in the User's manual.

Step 3: Connect the fireplace to a source of electricity.

Step 4: Place the burner and legs inside the casing. (If purchased, place the glass screen and holders on the top plate.)

Step 5: Turn on the fireplace. Fill in the right amount of bioethanol by verifying the level on the indicator.

Step 6: Start the fireplace by pressing the Play/Start button on the control panel.

Enjoy your fire.

DecoFlame Bluetooth Application Installation




App Store



Google play



Model:	Denver Basic 720 - black	CE
Dimensions:	720x215x125mm - Flame Tray 500	
Power Supply:	220/240V - 50Hz must be earthed	
Serial Number:	72000.05.16.V1.001	
Thermal Output:	max 2.9 kW	
Fuel Type:	bioethanol 96%	
Room Volume:	min. 58 m3	
Radio Frequency:	433.92 MHz	
Bluetooth Code:	0001	
Manufacturer:	DecoFlame ApS - Made in Denmark	




1. Download and install the DecoFlame App by scanning the QR code above corresponding to your smart device's operating system.

2. In order to pair your fireplace with your smart device, start the fireplace by pressing the 'ON' button.


Start the App and choose your fireplace. Insert the code from YOUR rating plate, like the one highlighted above.

3. Once your device is paired, the fireplace should be visible on the app. You are now able to change the name of the fireplace.


Note: You are able to pair more than one fireplace like described in the step nr. 2 and give them different names.



4. Once you have selected your fireplace, you can turn it on by pressing 'START'. If the fireplace has already been turned on using the control panel, you can now monitor the fuel level and the consumption.



5. For the 'Turn Off Timer' press the clock icon in the lower right corner. To adjust the remaining time, slide the dot to the left and right and select 'SET TIMER'. The remaining burning time can be changed by repeating the above mentioned steps. To cancel the timer select 'CLEAR TIMER'.





6. For adjusting the flame intensity, select the desired level on the left side of the screen. (1-lowest, 6-highest) Should there not be enough fuel for the selected burning time - the fireplace will shut down automatically. Select 'STOP' to turn off the fireplace.

WESTMINSTER BASIC™

www.decoflame.com

Cut-out dimensions



WESTMINSTER BASIC™

www.decoflame.com

It is imperative to follow the indications in the User's manual concerning the installation of decorative or electronic items above the fireplace. The dimensions below is valid for installing a TV over a westminster fireplace, even though it is not the one shown.

